


OPERATING INSTRUCTIONS

Model 879RMS

DIGITAL MULTIMETER



CE

CONTENTS

INTRODUCTION -----	1
UNPACKING AND INSPECTION -----	1
SAFETY INFORMATION -----	2
SYMBOL EXPLANATION -----	3
INSTRUMENT LAYOUT -----	4
HOW TO MAKE MEASUREMENTS -----	8
Voltage Measurements -----	8
Current Measurements -----	9
Resistance Measurements -----	11
Continuity Testing -----	11
Diode Testing -----	11
Logic Testing -----	11
Frequency and Duty Cycle Measurements -----	12
SPECIFICATIONS -----	13
MAINTENANCE -----	17
Replacing the Battery -----	17
Replacing the Fuse -----	18

INTRODUCTION

This manual contains information and warnings which must be followed to ensure safe operation and retain the meter in safe condition.

WARNING

READ "SAFETY INFORMATION" BEFORE USING THE METER.

This multimeter is a handheld, 20000-count instrument that is designed for use in the laboratory, field servicing, and at home. This meter features compact design with rounded corners for easy handling and has a rugged case in shock resistant and fire-retardant. Electronic overload protection for all functions and ranges. The Protective Holster (optional accessory) combined with rugged case make it a durable and reliable instrument.

UNPACKING AND INSPECTION

Upon removing your new Digital Multimeter (DMM) from its packing, you should have the following items:

1. Digital Multimeter
2. Test Lead Set (one black, one red)
3. 9-Volt Battery (installed in meter)
4. Instruction Manual
5. One Spare Fuse (500mA/600V, 6.3mm x 25mm, fast acting)

If any of the above items are missing or are received in a damaged condition, please contact the distributor from whom you purchased the unit.

SAFETY INFORMATION

Injury or death can occur even with low voltages and low currents. It is extremely important that you read these safety information before using your multimeter. Follow all safety practices and proper operating procedures for equipment being tested.


1. Exercise extreme caution when:
Measuring voltage above 20 volts, measuring current greater than 10mA, measuring AC power line with inductive loads, measuring AC power line during electrical storms.
2. Always inspect your DMM, test leads and accessories for any sign of damage or abnormality before every use. If any abnormal conditions exist (i.e., broken or damaged test leads, cracked case, display not reading, etc.), do not attempt to take any measurements.
3. Never ground yourself when taking electrical measurements. Do not touch exposed metal pipes, outlets, fixtures, etc., which might be at ground potential. Keep your body isolated from ground by using dry clothing, rubber shoes, rubber mats, or any approved insulating material.
4. Never touch exposed wiring, connections, test probe tips, or any live circuit conductors when attempting to make measurements.
5. Never replace the protective fuse inside the DMM with a fuse other than the specified or approved equal fuse.
6. Do not operate this instrument in an explosive atmosphere (i.e., in the presence of flammable gases or fumes, vapor or dust.)
7. Measuring voltage which exceeds the limits of the multimeter may damage the meter and expose the operator to a shock hazard. Always recognize the meter voltage limits as stated on the front of the meter.

8. Never apply more than 500VDC between the COM jack and earth ground.
9. Never touch a voltage source when the test leads are plugged into a current jack.
10. When testing for the presence of voltage or current, make sure the voltage or current ranges are functioning correctly. Take a reading of a known voltage or current before assuming a zero reading indicates no current or voltage.

SYMBOL EXPLANATION

	Attention! Refer to the Operating Instructions
	Dangerous Voltage May Be Present at terminals
	Ground
	AC - Alternating Current
	DC - Direct Current
	Audible Continuity / Diode
	Logic Test
	Double Insulation

INSTRUMENT LAYOUT



1 V Ω Hz \diamond \blacktriangleright Volt, Ohms, Frequency, Logic, Diode Input Terminal

This is the positive input terminal for all functions except current measurements. Connection is made to it using the red test lead.

2 COM Common Terminal

This is the negative (ground) input terminal for all measurement modes. Connection is made to it using the black test lead.

3 μ A mA Microamp/Milliamp Input Terminal

This is the positive input terminal for current measurement (ac or dc) up to 200 mA. Connection is made to it using the red test lead.

4 20A 20 Amperes Input Terminal

This is the positive input terminal for current measurement (ac or dc) up to 20A. Connection is made to it using the red test lead.

5 Function / Range Selector Rotary Switch

This rotary switch selects the function and range desired.

6 Data Hold Button

Press (HOLD) button to toggle in and out of the Data Hold mode. In the Data Hold mode, the "H" annunciator is displayed and the last reading is held on the display. Press the (HOLD) button again to exit and resume readings.

7 Power Button

This switch is used to turn meter on or off.

8 Other Functions

• Auto Power Off

Automatic power-off extends the life of the battery by turning the meter off. After approximately 45 minutes of inactivity. The meter turns back on if a POWER switch is pressed.

• **Input Warning Beeper**

The Input Warning Beeper is a feature to protect the meter and you from unintentional misuse. If the DMM is set to measure a voltage while the test leads are plugged into a current jack, very high current could result when the test lead tips are placed to the voltage test point. This feature warns you that the test lead needs to be changed from a current jack to the voltage jack.

All current ranges are fused with fast acting ceramic fuses as an added protection.

• **True RMS Measurements**

This multimeter permits direct measurement of the true RMS value of a signal. This is the best way to measure parameters used for measurements relating to power.

The relationship between the total true RMS (AC + DC) and the component AC and DC signals is given by the following expression:

$$\text{True RMS} = \sqrt{(\text{AC RMS Component})^2 + (\text{DC Component})^2}$$

RMS is equivalent to that DC value which dissipates the same amount of power in a resistor as the original signal and can be visualized by the relationships

$$\text{Power} = \frac{V_{RMS}^2}{R} = \frac{V_{DC}^2}{R}$$

"Average-responding" meters provide accurate RMS readings for sinusoidal signals, but can introduce significant errors when measuring nonsinusoidal waveforms. The following table shows the errors that result when the average-responding measurement is used instead of the True RMS value.

Power Calculations (watts) from Voltage Measurements (Vpk = 100V, Load = 1kΩ resistor)			
	AC RMS average responding	AC True RMS	Error
Sine wave	5.0	5.0	0%
Square wave	12.3	10.0	+23%
Triangle wave	3.1	3.3	-6%

This multimeter is AC coupled and will accurately measure the AC RMS component of an input signal. The DC voltage function will measure the DC component. To obtain the total true RMS value, measure the RMS AC component on the AC function and the DC component on the DC function. Then, calculate the True RMS value, using the measured AC and DC components and the True RMS expression given above.

AC converters of all types are limited by their frequency response and input dynamic range. Measurements of complex waveforms will not be affected by converter bandwidth limitations, provide that all significant AC components contained within the waveforms are within the bandwidth of the converter.

Crest factor is a measure of the input dynamic range of an AC converter. It expresses the ability of the converter to accept a signal that has large peak values compared to its RMS value without saturating the converter circuitry and degrading the specified accuracy. Crest factor is defined as the ratio of the peak voltage to the total AC RMS voltage.

$$\text{Crest Factor} = \frac{V(\text{PEAK})}{V(\text{AC RMS})}$$

HOW TO MAKE MEASUREMENTS

Before making any measurements always examine the instrument and accessories used with the instrument for damage, contamination (excessive dirt, grease, ect.) and defects. Examine the test leads for cracked or frayed insulation and make sure the lead plugs fit snugly into the instrument jacks. If any abnormal conditions exist do not attempt to make any measurements.

VOLTAGE MEASUREMENTS

1. Insert the black and red test leads into the COM and V- Ω input terminals respectively.
2. Select the desired AC voltage range (V \sim), or DC voltage range (V ---).

WARNING

To avoid possible electric shock, instrument damage and / or equipment damage, do not attempt to take any voltage measurements if the voltage is above 1000Vdc / 750Vac. 1000Vdc and 750Vac are the maximum voltages that this instrument is designed to measure. The "COM" terminal potential should not exceed 500V measured to ground.

3. Connect the test lead tips in parallel with the circuit to be measured (e.g. across a load or power supply). Be careful not to touch any energised conductors. Note the reading.
4. When all measurements are completed, disconnect the test leads from the circuit under test. Remove test leads from the multimeter.

For DC voltage readings, the RED lead tip should be connected to the positive side of the circuit, the BLACK lead to the negative side.

A minus sign on the left hand side of the LCD will appear if the leads are connected the other way round.

CURRENT MEASUREMENTS

These are made in series with the test circuit. All the current to be measured flows through the multimeter.

WARNING

Do not attempt to measure currents in high energy circuits capable of delivering greater than 600V. Since the fuse is rated at 600V damage or injury could occur. The 20A input terminal is protected by a 20A/600V high energy, fast blow fuse. The mA input terminal is protected by a 500mA/600V fast blow fuse.

Do not exceed the limits of each current input terminal. This is 20A (maximum time limit of 30 seconds for currents greater than 10A) for the 20A terminal and 200mA for the mA terminal.

All current ranges are fused. If a current greater than 20A on the 20A range or greater than 500mA on all other ranges flows, the fuse will blow causing an open circuit between the current measuring terminals.

1. Insert the BLACK test lead in the COM input terminal.
2. For measuring currents less than 200mA, connect the RED test lead to the mA input terminal. For measuring currents between 200mA and 20A connect the RED test lead to the 20A terminal.
3. Select the desired AC current range or DC current range.
4. Switch OFF or disconnect the circuit to be measured from all power sources, connect the multimeter in series with the conductor in which the current to be measured flows.
5. Switch ON the circuit. Note the reading.
6. Switch OFF or disconnect the circuit and remove the test leads from multimeter.

CAUTION

A common abuse of multimeters is to attempt to measure a voltage while the test leads are still plugged into the current input terminals. This basically puts a short circuit across the voltage source since current ranges have a low impedance. If the voltage source is typically 240VAC or a 3-phase industrial voltage (415V), very high fault currents can result. This is why all current input terminal are fused. If the fuses blow they must only be replaced by the equivalent ones otherwise the safety of the instrument may be impaired.

7. Never apply a voltage between the COM terminal and current terminals.
8. When switching between current ranges to obtain greater accuracy and better resolution, completely de-energise the circuit to be measured before changing the range.

RESISTANCE MEASUREMENTS

CAUTION

Turn off power on the test circuit and discharge all capacitors before attempting in-circuit resistance measurements. If an external voltage is present across a component, it will be impossible to take an accurate measurement of the resistance of that component.

1. Insert the BLACK and RED test leads into the COM and V Ω input terminals respectively.
2. Select the desired ohms (Ω) range.
3. Connect the BLACK and RED test probe tips to the circuit or device under test, making sure it is de-energised first.
4. Test lead resistance can interfere when measuring low resistance readings and should be subtracted from resistance measurements for accuracy. Select lowest resistance range and make the test leads short together. The display value is the test lead resistance to be subtracted.

CONTINUITY TESTING

1. Select the () position by turning the rotary selector switch.
2. Follow steps 1 and 3 as for resistance measurements.
An audible tone will sound for resistance less than approximately 150 Ω . After all measurements are completed, disconnect the test leads from the circuit and from the multimeter input terminals.

DIODE TESTING

CAUTION

Measurements must only be made with the circuit power OFF.

1. Set the rotary selector switch to the () position.
2. Follow steps 1 and 3 as for resistance measurements.
3. The RED lead should be connected to the anode and the BLACK lead to the cathode. The typical forward voltage drop should be about 0.7V for silicon diode or 0.4V for germanium diode.
4. If the diode is reverse biased or there is an open circuit the reading display shows "1".

LOGIC TESTING

1. Insert the BLACK and RED test leads into the "COM" and "V Ω " input terminals respectively.
2. Select the logic function by rotating the selector dial to the () logic position.
3. Connect the BLACK probe tip to the Common Bus of the logic circuitry to be measured.
4. Connect the RED probe tip to the point to be tested.
5. With a logic high pulse (1), the  indicator will display in the LCD and a beeping sound will emit. With a logic low pulse (0), the  indicator will appear in the LCD.

FREQUENCY AND DUTY CYCLE MEASUREMENTS

1. Set the rotary selector switch to the "Hz" range desired for a measurement.
2. Insert the BLACK and RED test leads into the "COM" and "VΩ" input terminals respectively.

CAUTION

The frequency ranges have overload protection to 500Vac/Vdc. DO NOT EXCEED THIS LIMIT. To do so could damage your multimeter.

3. Apply the test leads to the points across which the frequency is to be measured, and read the result directly from the display.
4. To make duty cycle test during frequency measurements, place the range selector switch into the "DUTY %" position. The display will indicate 0% to 90.0% of the frequency duty cycle.

SPECIFICATIONS

- **Display:** 4½ digits, 17mm large LCD maximum reading 19999 with function and unit sign annunciators.
- **Polarity:** Automatic, (-) negative polarity indication.
- **Overrange indication:** "1" most significant digit blinks.
- **Low battery indication:** The "  " is displayed when the battery voltage drops below the operating level.
- **Auto power off:** Meter automatically shuts down after approx. 45 minutes of inactivity.
- **Measurement rate:** 2.5 times per second, nominal.
- **Operating environment:** 0°C to 50°C at < 70% R.H.
- **Storage temperature:** -20°C to 60°C, 0 to 80% R.H. with battery removed from meter.
- **Power:** Single 9V battery, NEDA 1604, JIS 006P, IEC 6F22.
- **Battery life:** 300 hours typical with carbon-zinc.
- **Dimensions:** 189mm (H) x 87mm (W) x 37mm (D).
- **Weight:** Approx. 330g including battery.

* Accuracy is given as \pm [(% of reading) + [number of least significant digits)] at 18°C to 28°C, with relative humidity up to 70%.

DC Volts

Range	Resolution	Accuracy	Input Impedance
200mV	10μV	$\pm(0.05\% \text{ rdg} + 3d)$	10MΩ
2V	100μV	$\pm(0.05\% \text{ rdg} + 3d)$	10MΩ
20V	1mV	$\pm(0.05\% \text{ rdg} + 3d)$	10MΩ
200V	10mV	$\pm(0.05\% \text{ rdg} + 3d)$	10MΩ
1000V	100mV	$\pm(0.05\% \text{ rdg} + 3d)$	10MΩ

Overload Protection: 500VDC / 350VRMS on 200mV range
1000VDC / 750VRMS on all other ranges

AC Volts (True RMS)

Range	Resolution	Accuracy(50Hz to 500Hz)	500Hz to 2KHz
200mV	10 μ V	$\pm(1.0\% \text{ rdg} + 10\text{d})$	$\pm(2.0\% \text{ rdg} + 20\text{d})$
2V	100 μ V	$\pm(1.0\% \text{ rdg} + 10\text{d})$	$\pm(2.0\% \text{ rdg} + 20\text{d})$
20V	1mV	$\pm(1.0\% \text{ rdg} + 10\text{d})$	$\pm(2.0\% \text{ rdg} + 20\text{d})$
200V	10mV	$\pm(1.0\% \text{ rdg} + 10\text{d})$	$\pm(2.0\% \text{ rdg} + 20\text{d})$
750V	100mV	$\pm(2.0\% \text{ rdg} + 20\text{d})$	Unspecified

Input Impedance: 10M Ω

Overload Protection: 500VDC / 350VRMS on 200mV range
1000VDC / 750VRMS on all other ranges

DC Current

Range	Resolution	Accuracy	Voltage Burden
200 μ A	10nA	$\pm(0.5\% \text{ rdg} + 5\text{d})$	300mV
2mA	100nA	$\pm(0.5\% \text{ rdg} + 5\text{d})$	300mV
20mA	1 μ A	$\pm(0.5\% \text{ rdg} + 5\text{d})$	300mV
200mA	10 μ A	$\pm(0.5\% \text{ rdg} + 5\text{d})$	600mV
20A**	1mA	$\pm(2.0\% \text{ rdg} + 10\text{d})$	800mV

Overload Protection: 500mA/600V fuse on mA inputs (fast blow ceramic fuse). 20A/600V fuse on 20A inputs(fast blow ceramic fuse).
** 20A for 30 seconds maximum.

AC Current (True RMS)

Range	Resolution	Accuracy (50Hz-1KHz)	Burden Voltage
200 μ A	10nA	$\pm(0.8\% \text{ rdg} + 10\text{d})$	300mV
2mA	100nA	$\pm(0.8\% \text{ rdg} + 10\text{d})$	300mV
20mA	1 μ A	$\pm(0.8\% \text{ rdg} + 10\text{d})$	300mV
200mA	10 μ A	$\pm(0.8\% \text{ rdg} + 10\text{d})$	600mV
20A**	1mA	$\pm(2.5\% \text{ rdg} + 10\text{d})$	800mV

Overload Protection: 500mA/600V fuse on mA inputs (fast blow ceramic fuse). 20A/600V fuse on 20A inputs(fast blow ceramic fuse).
** 20A for 30 seconds maximum.

Resistance

Range	Resolution	Accuracy	Open Circuit Volts
200 Ω	10m Ω	$\pm(0.25\% \text{ rdg} + 10\text{d})$	$\approx 3.3\text{Vdc}$
2k Ω	0.1 Ω	$\pm(0.15\% \text{ rdg} + 3\text{d})$	$\approx 3.3\text{Vdc}$
20k Ω	1 Ω	$\pm(0.15\% \text{ rdg} + 3\text{d})$	$\approx 3.3\text{Vdc}$
200k Ω	10 Ω	$\pm(0.15\% \text{ rdg} + 3\text{d})$	$\approx 3.3\text{Vdc}$
2M Ω	100 Ω	$\pm(0.25\% \text{ rdg} + 10\text{d})$	$\approx 3.3\text{Vdc}$
20M Ω	1k Ω	$\pm(1.0\% \text{ rdg} + 10\text{d})$	$\approx 3.3\text{Vdc}$

Overload Protection: 500V DC or RMS AC

Continuity Test

Range	Audible Threshold	Response Time	Open Circuit Volts
2V	Less than 150 Ω	Approx. 500ms	3.3Vdc typical

Overload Protection: 500V DC or RMS AC

Diode Test

Range	Resolution	Accuracy	Test Current	Open Circuit Volts
2V	0.1mV	$\pm(0.5\% \text{ rdg} + 1\text{d})$	1.0mA	3.3Vdc typical

Overload Protection: 500V DC or RMS AC

Logic Test

Thresholds		Pulse Rise (max.)	Pulse Rep (max.)	Pluse Width (min.)
Logic 1 (Hi)	Logic 0 (Lo)			
2.8V \pm 0.8V	0.8V \pm 0.5V	10 μ Sec	1Mpps	25nS

Test Voltage: 5VDC

Duty Cycle: >20% and <80%

Frequency Response: 20MHz

Indication: 40msec beep at logic 1 (Hi)

Overload Protection: 500VDC or RMS AC

Frequency

Range	Resolution	Accuracy	Input Impedance
2kHz	0.1Hz	$\pm(0.5\% \text{ rdg} + 3\text{d})$	10M Ω /10pF
20kHz	1Hz	$\pm(0.5\% \text{ rdg} + 3\text{d})$	10M Ω /10pF
200kHz	10Hz	$\pm(0.5\% \text{ rdg} + 3\text{d})$	10M Ω /10pF

Sensitivity: 50mV RMS min. (Sine Wave)

400mV RMS min. at >30% and <70% duty cycle

Effect reading: More than 10Hz at pulse width >2 μ Sec

Overload protection: 500VDC or RMS AC

Duty Cycle

Range	Resolution	Pulse Width	Accuracy (5V Logic)
0 to 90.0%	0.1%	>10 μ Sec	$\pm(2.0\% \text{ rdg} + 10\text{d})$

Frequency range: 20Hz to 20kHz

Overload protection: 500VDC or RMS AC

MAINTENANCE

Repairs or servicing not covered in this manual should only be performed by qualified personnel.

REPLACING THE BATTERY

WARNING

TO AVOID ELECTRICAL SHOCK, DISCONNECT THE TEST LEADS AND ANY INPUT SIGNALS BEFORE REPLACING THE BATTERY. REPLACE ONLY WITH SAME TYPE OF BATTERY.

This meter is powered by a NEDA type 1604 or equivalent 9-volt battery.

When the multimeter displays the "  " the battery must be replaced to maintain proper operation. Use the following procedure to replacing the battery:

1. Disconnect test leads from any live source, turn the rotary switch to OFF, and remove the test leads from the input terminals.
2. The case bottom is secured to the case top by three screws and two internal snaps (at the LCD end). Using a Phillips-head screwdriver, remove the three screws from the case bottom and turn the case over.
3. Lift the input terminal end of the case bottom until it gently unsnaps from the case top at the end nearest the LCD.
4. Remove battery and replace with a new equivalent 9-volt battery.
5. Replace the case bottom, ensuring that the two snaps on the case top (at the end near the LCD) are engaged. Reinstall the three screws.

P/N 7000-1328

March 1994